


DC Master Distribution Panel

s.v.Woody II





NavPanel
s.v. Woody II

31

Bilgepump
left

32

Bilgepump
right

12,34V

15,00A

House Battery

12,34V

Engine Starting
battery



3



1

NavLight

2



2

Navlight
motor

2



3

Anchor
Light

6



4

Deck
Light

6



5

Lights
Left cabin

6



6

Lights
Saloon

6



7

Lights
right cabin

2



8

Red Light
Saloon

10



9

HiFi

10



10

Fridge

5



11

PS

5



12

USB
saloon

6



13

USB
cabin

8



14

Shower
pump

10



15

Wipers
motor

5



16

Heater

15



17

Water
pump

3



18

TV

8



19

Horn

5



20

2



21

Central
nav

5



22

VHF

3



23

GPS

2



24

Depth

2



25

Speed

5



26

Radar

5



27

AIS

3



28

Navtex

5






29

Autopilot

8



30



NavPanel
s.v. Woody II

12,34V
15,00A


12,34V

32
A-6

31
A6

F1----- 30
Fusses

view of the back side



1. NavLight



2. NavLight Motor



3. Anchor Light



4. Deck Light



5. Lights Left cabins



6. Lights Salon




7. Lights right cabins



8. Red Light Salon




9. HiFi



10. Fridge



11. PS



12. USB socket Salon



13.USB socket cabins



14. Shower pump

15. Wipers motor



16. Heater

17. Water Pump

18. TV



19. Horn



20.

21. Central navigation

22. VHF

23. GPS



24. Depth sonar

25. Speed

26. Radar


27. AIS

28. Navtex

29. Autopilot

30.

AC 220v distrb.
s.v.Woody II



△ 220v
Main BP220v
Chardger batt.220v12v

