

Venting (second deck)
Venting (second deck)
Filling connection
Day tank 500 litre
level gauge
low level alarm
water tap
New tank 6000 litre
New tank 3000 litre
Original tank 11000 litre
level gauge
Sideview
water tap
Manual pump
Seperator
Fuel Pump
filters
Main Engine
Generator 1
Generator 2
CV heater
Hydro engine
Emergency generator
filter
New tank 6000 litre
Sideview
water tap
Original tank 11000 litre
New tank 3000 litre
level gauge
Venting (second deck)
Filling connection
=Filter
=Pump
=Pump manual
=Valve
=Direction
Diesel storage tanks Diagram
SRF
Scheepsreparatie Friesland
Koningsweg 27
8861 KN Harlingen
Tel : 0031 517-417523
Fax : 0031 517-430998
Mob : 0031 610791605
Email : wychard@srfholland.nl
Web : www.srfholland.nl